


Setup

WARNING:

To prevent electric shock, always POWER OFF all devices while setting up the connections



English

1 Using HDMI Cable

The HDMI connection is recommended for Digital TV.

1. Connect your CATV line to the CABLE IN.
2. Connect the product and TV using an HDMI cable.

2 Using an HDMI-to-DVI Converter

The HDMI-to-DVI connection with converter is recommended for Digital TV.

1. Connect your CATV line to the CABLE IN.
2. Connect one end of the HDMI cable to the HDMI input on the product and the other end to the HDMI-to-DVI converter.
3. Connect the HDMI-to-DVI converter to the DVI input on the TV.
4. **1) When using the digital audio system**, connect the product and the digital audio system using an S/PDIF cable.
2) Otherwise, connect the product and the TV using an RCA cable (Audio L/R).

3 Using Component Cable

The component connection is recommended for Digital TV.

1. Connect your CATV line to the CABLE IN.
2. Connect the product and the TV using a component cable.
3. **1) When using the digital audio system**, connect the product and the digital audio system using an S/PDIF cable.
2) Otherwise, connect the product and the TV using an RCA cable (Audio L/R).

Note: The **Component Selection** menu should be set to **YpBPr** when using the SCART cable.

4 Using SCART Cable

A SCART cable connection is recommended for analogue TV or VCR.

1. Connect your CATV line to the CABLE IN.
2. Connect the product and the TV using a SCART cable.
3. Connect the product and the VCR using a SCART cable.

Note: The **Component Selection** menu should be set to **RGB** when using the SCART cable.

Nederlands

1 Een HDMI-kabel gebruiken

Voor digitale televisie wordt de HDMI-aansluiting aanbevolen.

1. Sluit de antenne-kabel aan op de CABLE IN-aansluiting.
2. Sluit de iHDR5050C aan op de televisie met een HDMI-kabel.

2 Een HDMI-DVI-converter gebruiken

Een HDMI-DVI-verbinding met converter is geschikt voor digitale televisie.

1. Sluit de antenne-kabel aan op de CABLE IN-aansluiting.
2. Sluit de HDMI-kabel aan op de HDMI-ingang van de iHDR5050C en op de HDMI-DVI-converter.
3. Sluit de HDMI-DVI-converter aan op de DVI-ingang van de televisie.
4. **1) Wanneer u gebruik maakt van een digitaal audiosysteem** verbindt u de iHDR5050C en het digitale audiosysteem door middel van een S/PDIF-kabel.
2) Als u geen gebruik maakt van een digitaal audiosysteem sluit u de iHDR5050C aan op de televisie met een RCA-kabel (Audio L/R).

3 Een componentkabel gebruiken

De componentaansluiting wordt aanbevolen voor digitale TV.

1. Sluit de antenne-kabel aan op de CABLE IN-aansluiting.
2. Sluit de iHDR5050C met een componentkabel aan op de televisie.
3. **1) Wanneer u gebruik maakt van een digitaal audiosysteem** verbindt u de iHDR5050C en het digitale audiosysteem door middel van een S/PDIF-kabel.
2) Als u geen gebruik maakt van een digitaal audiosysteem sluit u de iHDR5050C aan op de televisie met een RCA-kabel (Audio L/R).

Opmerking: het menu **Componentkeuze** moet op **YpBPr** zijn ingesteld wanneer u de componentkabel gebruikt.

4 Een SCART-kabel gebruiken

Voor analoge televisie of video wordt aansluiting via een SCART-kabel aangeraden.

1. Sluit de antenne-kabel aan op de CABLE IN-aansluiting.
2. Sluit de iHDR5050C met een SCART-kabel aan op de televisie.
3. Sluit de iHDR5050C met een SCART-kabel aan op de videorecorder.

Opmerking: het menu **Componentkeuze** moet op **RGB** zijn ingesteld wanneer u de SCART-kabel gebruikt.